



TrueFace50FP Back to Back (Connection Diagram)



TrueFace50FP with Push Button (Connection Diagram)



TrueFace50FP with any Wiegand Reader (Connection Diagram)

