

## QR Reader Connection Diagram



Wire connection:

Colour	WG26/34/66	RS485	RS232
Red	DC5-15V	DC5-15V	DC5-15V
Black	GND	GND	GND
Green	D0	4R+	RX
White	D1	4R-	TX
Blue	LED		
Yellow	BEEP		
Gray	WG26/34		

For QR Generation need to make QR in 10 digit only; like if output needed 12345, QR will be generated 0000012345.

To Change bit from 26 to 34 Weigand need to connect Gray Cable with Black (GND).



(+91)-11-41916615  
+91-95999-53923



D-162, Okhla Industrial Area  
Phase I, New Delhi, 110020



sales@timewatchindia.com  
www.timewatchindia.com